5970858
AN Hanging Magazine Rack

Parts and Hardware List

A.	Racks	2 pcs
B.	Long Felt Lining	2 pcs
C.	Short Felt Lining	2 pcs
D.	Hooks	2 pcs
E.	Metal Plates	2 pcs
F.	Phillips Head Screws	12 pcs
G.	Phillips Head Screwdriver	1 pc

∗ Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
∗ Use the hardware illustrations to determine correct piece and size.
∗ This item should be assembled on a soft surface to prevent scratching the finish during assembly.
∗ This item may require periodic tightening.

Hardware Illustrations



F. Phillips Head Screw

5970858
AN Hanging Magazine Rack

Assembly Instructions

1. **Attach Metal Plates (F)** Put both Racks (A) face down on a soft surface. Align the pre-drilled holes in one end of the Metal Plate (E) with the pre-drilled holes in the bottom back panel of the top Rack (A). Make sure the pre-drilled holes in the lower end of the Metal Plate (E) align with the pre-drilled holes in the top back panel of the lower Rack (A). Secure with Phillips Head Screws (F) using Phillips Head Screwdriver (G). Repeat Step 1 for Metal Plates (E) on opposite side. See Illustration .
2. **Attach Hooks (D)** Align the pre-drilled holes in the long part of Hooks (D) with the pre-drilled holes in the top back panel of the top Rack (A). Secure with Phillips Head Screws (F) through the pre-drilled holes in the short part of Hooks (D) using Phillips Head Screwdriver (G). See Illustration.
3. **Attach Long & Short Felt Lining (B, C**) Remove cover from Long & Short Felt Linings (B, C). Cover the Metal Plates (E) using the Long Felt Linings (B). Cover the Hooks (D) inside using the Short Felt Linings (C). See Illustration.



Illustration